


REFLECTIVE BARS - STANDARD CONFIGURATION

Applying the reflective bars

1. Peel backing from the reflective bars.
2. Place the adhesive side down in five (5) locations, as shown.



For More Information, call 1-800-MSA-2222 or Visit Our Website at www.MSAnet.com



MINE SAFETY APPLIANCES COMPANY
PITTSBURGH, PENNSYLVANIA, U.S.A. 15230

MSA 808 (L) Rev. 0


© MSA 2008

Print Spec. 1000005196 (S) Mat. 10096153
Doc. 10096153

REFLECTIVE BARS - STANDARD CONFIGURATION

Applying the reflective bars

1. Peel backing from the reflective bars.
2. Place the adhesive side down in five (5) locations, as shown.



For More Information, call 1-800-MSA-2222 or Visit Our Website at www.MSAnet.com



MINE SAFETY APPLIANCES COMPANY
PITTSBURGH, PENNSYLVANIA, U.S.A. 15230

MSA 808 (L) Rev. 0

© MSA 2008

Print Spec. 1000005196 (S) Mat. 10096153
Doc. 10096153