995

996

1 Ton Capacity, Adjustable Jaw Puller

Part No.	Description	Reach max.	Spread max.	Screw Size	Weight
995	2 Jaw	2 1/8″	3 1/4″	5/16″-24 x 3 7/8″ lg.	0.3 lb.
996	3 Jaw	2 1/8″	3 1/4″	5/16″-24 x 3 7/8″ lg.	0.5 lb.

999A

PO10A

2 Ton Capacity, Adjustable & Reversible Jaw Puller

Part No.	Description	Reach max.	Spread max.	Screw Size	Weight
999A	2 Jaw	3 3/8″	4″	3/8″-24 x 4 7/8″ lg.	0.9 lb.
PO10A	3 Jaw	3 3/8″	4 3/4″	3/8″-24 x 4 7/8″ lg.	1.3 lbs.

1001

PO11

5 Ton Capacity, Reversible Jaw Puller

Part No.	Description	Reach max.	Spread max.	Screw Size	Weight
1001	2 Jaw	3 1/4″	6″	9/16″-20 x 6 15/16″ lg.	1.8 lbs.
PO11	2/3 Jaw	3 1/4″	7″	9/16″-20 x 6 15/16″ lg.	2.8 lbs.

999LA

PO13A

5 Ton Capacity, Adjustable & Reversible Jaw Puller

Part No.	Description	Reach max.	Spread max.	Screw Size	Weight
999LA	2 Jaw	5 1/2″	6″	9/16″-20 x 6 15/16″ lg.	2 lbs.
PO13A	2/3 Jaw	5 1/2″	7″	9/16″-20 x 6 15/16″ lg.	3.5 lbs.

CAUTION

- Be sure puller is aligned & jaws are fully seated on part to be pulled.
- Do not modify or heat puller parts; this causes loss of strength and voids the product warranty.
- When possible use a larger sized puller to avoid potential overloading.